



CREATOR

20015






1




2



3



4






1




2




4x


5




6





7






9







10




11




12







1




2




3




4




4



5




13




1




2




3




4



5




14







1




2




3




4



5




6







7




8



9



15





2x
4113917



1x
4546367



3x
4114309



2x
4124067



1x
306821



3x
307021



2x
403224



5x
4504369



4x
302401



3x
4107736



3x
303928



6x
302328



2x
302228



4x
4157120



3x
4556159



3x
4521931



5x
4107758



6x
302028



2x
366628



1x
379528



1x
4535738



2x
4205469



2x
4205470



1x
4520300



4x
4210632



2x
614126



16x
4504372



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

www.lego.com/service or dial



00800 5346 5555 :



1-800-422-5346 :



www.LEGO.com

©2010 The LEGO Group. 4584863